



SCK GND
 TP44 TP45 R40 TP48
 3V8 TP40 PWDN
 SDA0 TP46
 SCL0 TP47 Cam_VDD

USB_ON/OFF

CLK2 DAT2



TP49 SD_VDD
 SD_2_0

